

Volkswagen Ver.: 25.80

MODEL	SYSTEM	TYPE	System Info.	Read-Clear Dtc	Data stream	Actuation	Specail Functions
Bora	03 Brake Electronics	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	03 Brake Electronics	(01-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	25 Immobilizer	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	71 Battery charger	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	61 Battery control	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	43 BRAKER BOOST.ASSI.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	46 Central Control Module	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CHASSIS NETWORK	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLUTCH ELECTRONI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CRUISE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER FOOT BOAR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SEAT CONTR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC ACTUATIO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC STEERING	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	FRONT CONTR.INDIC	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	HEADLIGHT LEVEL	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	IMMOBILIZER	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	LEFT REAR DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PARK.BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PARKING HELP	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS. SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS.FOOT BOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASSIVE ENTRY	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	POWER BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RADIO / CD	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR CONTROL INDI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REMOTE CONTROL E	(99..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RIGHT REAR DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SEAT/MIRROR POS.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(99..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SUSPENSION CONTR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TRACTION CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TV SYSTEM	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	VOICE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Caddy	03 Brake Electronics	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 1.9 TDI	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Caravele	03 Brake Electronics	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	46 Central Control Module	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Corrado	03 Brake Electronics	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	46 Central Control Module	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Fox	15 Airbags	(.-05)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CHASSIS NETWORK	(.-05)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(.-05)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(.-05)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC STEERING	(.-05)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-05)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(.-05)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Golf IV	03 Brake Electronics	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	03 Brake Electronics	(01-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	25 Immobilizer	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	49 Auto. Lighting switch	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	71 Battery charger	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

61 Battery control	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
43 BRAKER BOOST.ASSI.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
46 Central Control Module	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CHASSIS NETWORK	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CLIMA	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CLUTCH ELECTRONI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
COMFORT SYSTEM	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CONV. TOP/SUNROO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CRUISE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DASHBOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DISTANCE REGULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER FOOT BOAR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER SEAT CONTR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC ACTUATIO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC STEERING	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
EMERGENCY CALL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
FRONT CONTR.INDIC	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
HEADLIGHT LEVEL	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
IMMOBILIZER	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LEFT REAR DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LH RIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARK.BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARKING HELP	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS. SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS.FOOT BOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASSIVE ENTRY	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
POWER BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
RADIO / CD	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	REAR CONTROL INDI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REMOTE CONTROL E	(99-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RH LIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RIGHT REAR DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SEAT/MIRROR POS.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(.-5/99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(99-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SOUND SYSTEM	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SUSPENSION CONTR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SWITCH PANEL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TRACTION CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TV SYSTEM	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	VOICE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Golf Plus	03 Brake Electronics	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CENTRAL ELECTRIC	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SIDE DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC STEERING	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 1.9 TDI BKC	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 2.0 TDI BKD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	LEFT REAR DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS. SIDE DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RADIO / CD	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RIGHT REAR DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	SERVICE LIGHT RES	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TRANSPORT MODALI	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Golf V	03 Brake Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CENTRAL ELECTRIC	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SIDE DOOR	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC STEERING	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 1.9 TDI BKC	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 2.0 TDI BKD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	LEFT REAR DOOR	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS. SIDE DOOR	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RADIO / CD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RIGHT REAR DOOR	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
STEERING WHEEL	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>	
TRANSPORT MODALI	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>	
Golf	03 Brake Electronics	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	46 Central Control Module	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	ENGINE MANAGEME	(..6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(..6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
JETTA	03 Brake Electronics	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CENTRAL ELECTRIC	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SIDE DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC STEERING	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 1.9 TDI BKC	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 2.0 TDI BKD	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	LEFT REAR DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS. SIDE DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RADIO / CD	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RIGHT REAR DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TRANSPORT MODALI	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Lupo	03 Brake Electronics	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	03 Brake Electronics	(01-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(..03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	71 Battery charger	(..00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

61 Battery control	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
43 BRAKER BOOST.ASSI.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
46 Central Control Module	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CHASSIS NETWORK	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CLIMA	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CONV. TOP/SUNROO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DASHBOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DISTANCE REGULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER FOOT BOAR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC ACTUATIO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC STEERING	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
EMERGENCY CALL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
FRONT CONTR.INDIC	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
IMMOBILIZER	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LH RIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARK.BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS. SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS.FOOT BOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASSIVE ENTRY	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
POWER BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
REAR CONTROL INDI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
RH LIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
SERVICE LIGHT RES	(.-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
SERVICE LIGHT RES	(99-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
SOUND SYSTEM	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
TV SYSTEM	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
VOICE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

New Beetle	03 Brake Electronics	(01-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	25 Immobilizer	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	49 Auto. Lighting switch	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	71 Battery charger	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	61 Battery control	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	43 BRAKER BOOST.ASSI.	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	46 Central Control Module	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CHASSIS NETWORK	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLUTCH ELECTRONI	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CRUISE CONTROL	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DISTANCE REGULATI	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER FOOT BOAR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SEAT CONTR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SIDE DOOR	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC ACTUATIO	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC STEERING	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	EMERGENCY CALL	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	FRONT CONTR.INDIC	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	HEADLIGHT LEVEL	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LH RIGHT MODULATI	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>	
PARK.BRAKE	(..-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>	

	PARKING HELP	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS. SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS.FOOT BOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASSIVE ENTRY	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	POWER BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RADIO / CD	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR CONTROL INDI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RH LIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SEAT/MIRROR POS.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(99-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SUSPENSION CONTR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SWITCH PANEL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TRACTION CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TV SYSTEM	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	VOICE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Passat Variant	03 Brake Electronics	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CENTRAL ELECTRIC	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CHANGE BRAKE PAD	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SIDE DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC STEERING	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 1.9 TDI	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 2.0 TDI	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	LEFT REAR DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PARK.BRAKE	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS. SIDE DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	RADIO / CD	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RIGHT REAR DOOR	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TRANSPORT MODALI	(05-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Passat	03 Brake Electronics	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	03 Brake Electronics	(01-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	03 Brake Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	25 Immobilizer	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	49 Auto. Lighting switch	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission ElectronicsI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	71 Battery charger	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	61 Battery control	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	43 BRAKER BOOST.ASSI.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CENTRAL ELECTRIC	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	46 Central Control Module	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CHANGE BRAKE PAD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CHASSIS NETWORK	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLUTCH ELECTRONI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CRUISE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER FOOT BOAR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SEAT CONTR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

DRIVER SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER SIDE DOOR	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC ACTUATIO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC STEERING	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC STEERING	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
EMERGENCY CALL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME 1.9 TDI	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME 2.0 TDI	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
FRONT CONTR.INDIC	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
HEADLIGHT LEVEL	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
IMMOBILIZER	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LEFT REAR DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LEFT REAR DOOR	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LH RIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARK.BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARK.BRAKE	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARKING HELP	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS. SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS. SIDE DOOR	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS.FOOT BOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASSIVE ENTRY	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
POWER BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
RADIO / CD	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
RADIO / CD	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
REAR CONTROL INDI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
RH LIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
RIGHT REAR DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
RIGHT REAR DOOR	(04..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	SEAT/MIRROR POS.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(99-04)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SUSPENSION CONTR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SWITCH PANEL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TRACTION CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TRANSPORT MODALI	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TV SYSTEM	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	VOICE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Phaeton	4WD ELECTRONICS	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	4WD ELECTRONICS	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	03 Brake Electronics	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	61 Battery control	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CENTRAL ELECTRIC	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CHASSIS MANAGEME	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COLUMN/SEAT REG.	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COLUMN/SEAT REG.	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CRUISE CONTROL	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DIGITAL RADIO TUNE	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

DIGITAL RADIO TUNE	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DIGITAL TV TUNER	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DISTANCE REGULATI	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DISTANCE REGULATI	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER IDENT.	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER SIDE DOOR	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECT. CENTRAL SY	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC STEERING	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
EMERGENCY MODUL	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
EMERGENCY MODUL	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME V10 TDI	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
HATCHBACK DOOR E	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
HEADLIGHT LEVEL	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
HEADLIGHT LEVEL	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
IDENT./COMMAND UN	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
IDENT./COMMAND UN	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
IMMOBILIZER	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
IND./COMMAND UNIT	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
IND./COMMAND UNIT	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LANE CHANGE ASSY	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LANE MANT. ASSYST.	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LEFT REAR DOOR	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
MEDIA PLAYER POSI	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
MEDIA PLAYER POSI	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
MEDIA PLAYER POSI	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
NAVIGATION	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARKING HELP	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS. SIDE DOOR	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASSENGER SEAT R	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASSENGER SEAT R	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PHONE	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PHONE	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	RADIO / CD	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR CLIMA	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR CLIMA	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR CONTROL INDI	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR SEAT REG.	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR SEAT REG.	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RIGHT REAR DOOR	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ROOF MANAGEMENT	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ROOF MANAGEMENT	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SAT. RADIO TUNER	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SOUND SYSTEM	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SPECIAL FUNCTION	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SUSPENSION CONTR	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TIRE PRESSURE	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TV SYSTEM	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TV SYSTEM	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	VEICHL E POSITION R	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	VEICHL E POSITION R	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	WIPERS	(02-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Polo	03 Brake Electronics	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	03 Brake Electronics	(01-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	25 Immobilizer	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	49 Auto. Lighting switch	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	71 Battery charger	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	61 Battery control	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	43 BRAKER BOOST.ASSI.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	46 Central Control Module	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CHASSIS NETWORK	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

CLUTCH ELECTRONI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
COMFORT SYSTEM	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CONV. TOP/SUNROO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CRUISE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DASHBOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DISTANCE REGULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER FOOT BOAR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER SEAT CONTR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC ACTUATIO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC STEERING	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
EMERGENCY CALL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME 1.0 AUC	(00-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
FRONT CONTR.INDIC	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
HEADLIGHT LEVEL	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
IMMOBILIZER	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LEFT REAR DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LH RIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARK.BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARKING HELP	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS. SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS.FOOT BOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASSIVE ENTRY	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
POWER BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
RADIO / CD	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
REAR CONTROL INDI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
RH LIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
RIGHT REAR DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
SEAT/MIRROR POS.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(99-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SUSPENSION CONTR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SWITCH PANEL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TRACTION CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	VOICE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Sharan	03 Brake Electronics	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	49 Auto. Lighting switch	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	71 Battery charger	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	61 Battery control	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	43 BRAKER BOOST.ASSI.	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	46 Central Control Module	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER FOOT BOAR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC ACTUATIO	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC STEERING	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	EMERGENCY CALL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	FRONT CONTR.INDIC	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	LEFT REAR DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	LH RIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	NAVIGATION	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	PARK.BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS. SIDE DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS.FOOT BOARD	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASSIVE ENTRY	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	POWER BRAKE	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR CONTROL INDI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RH LIGHT MODULATI	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RIGHT REAR DOOR	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(99-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SOUND SYSTEM	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SWITCH PANEL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TV SYSTEM	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	VOICE CONTROL	(.-00)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Taro	15 Airbags	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(.-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Touareg	4WD ELECTRONICS	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	4WD ELECTRONICS	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	03 Brake Electronics	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	03 Brake Electronics	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CENTRAL ELECTRIC	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CENTRAL ELECTRIC	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

CHASSIS MANAGEME	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CLIMA	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CLIMA	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
COLUMN/SEAT REG.	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
COLUMN/SEAT REG.	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
COMFORT SYSTEM	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
COMFORT SYSTEM	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CRUISE CONTROL	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
CRUISE CONTROL	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DASHBOARD	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DASHBOARD	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER IDENT.	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
DRIVER SIDE DOOR	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECT. CENTRAL SY	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ELECTRIC STEERING	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
EMERGENCY MODUL	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
ENGINE MANAGEME V10 TDI	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
HEADLIGHT LEVEL	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
HEADLIGHT LEVEL	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
IMMOBILIZER	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LANE CHANGE ASSY	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LANE MANT. ASSYST.	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LEFT REAR DOOR	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
LH RIGHT MODULATI	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
MEDIA PLAYER POSI	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
NAVIGATION	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARKING HELP	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PARKING HELP	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASS. SIDE DOOR	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASSENGER SEAT R	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PASSENGER SEAT R	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
PHONE	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	RADIO / CD	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RADIO / CD	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR CLIMA	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR CLIMA	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR SEAT REG.	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	REAR SEAT REG.	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RH LIGHT MODULATI	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RIGHT REAR DOOR	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ROOF MANAGEMENT	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SOUND SYSTEM	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SPECIAL FUNCTION	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STABILIZERS	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TV SYSTEM	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TV SYSTEM	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	VEICHL E POSITION R	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	VEICHL E POSITION R	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	WIPERS	(03-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Touran	03 Brake Electronics	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	7D Auxiliary Heater	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CENTRAL ELECTRIC	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	COMFORT SYSTEM	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CONV. TOP/SUNROO	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DRIVER SIDE DOOR	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ELECTRIC STEERING	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 1.9 TDI BKC	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME 2.0 TDI BKD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

	IMMOBILIZER	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	LEFT REAR DOOR	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	PASS. SIDE DOOR	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RADIO / CD	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	RIGHT REAR DOOR	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	STEERING WHEEL	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	TRANSPORT MODALI	(04-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Transporter	03 Brake Electronics	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(..-6/98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(99-..)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
Vento	03 Brake Electronics	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	15 Airbags	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	02 Transmission Electronicsl	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	46 Central Control Module	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CHASSIS NETWORK	(..-03)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	CLIMA	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	DASHBOARD	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	ENGINE MANAGEME	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	IMMOBILIZER	(..-99)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(93-96)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	SERVICE LIGHT RES	(98-98)	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
before 2007	01 Engine electronics		<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	11 Engine electronics 2		<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
	21 Engine electronics 3		<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

02 Transmission Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
03 Brake Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
08 AC/Heating electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
25 Immobilizer	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
47 Soundsystem	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
12 Clutch electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
34 Self leveling suspension	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
15 Airbags	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
16 Steering Wheel Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
44 Steering assistance	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
35 Central Locking	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
14 Wheel damping electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
17 Instrument Cluster	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
18 Aux heating	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
13 Distance control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
19 Gateway data bus	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
26 Electric roof control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
29 Left light control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
39 Right light control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
37 Navigation	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
45 Interior Monitoring	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
46 Central Control Module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
49 Auto. Lighting switch	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
51 Electric drive	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
61 Battery control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
75 Emergency call module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
76 Parking aid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
09 Electronic Ctrl Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
22 4WD Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
24 Drive slip control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
36 Driver`s side seat adj.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
41 Diesel pump electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
55 Headlight range control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
56 Radio	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

65 Type pressure monitoring	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
66 Seat-/mirror adjust.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
71 Battery charger	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
52 PASSE.-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
72 RR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
23 BRAKER BOOSTER	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
43 BRAKER BOOST.ASSI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
63 DRVS BOARDING ASS1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
73 DRVS BOARDING ASS2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
54 Rear spoiler	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
05 ACCESS & PERMISSI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
06 PASSENE. SEAT ADJ.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
07 DISPLAY-/CNTL UNIT	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
27 DIS./CTL UNIT REAR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
57 TV-TUNER	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
67 VOICE CONTROL	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
77 TELEPHONE	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
48 DRVS SEAT ADJ.REAR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
68 WIPER ELECTRONICS	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
78 SLIDING DOOR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
59 TOWING PROTECTION	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
69 TRAILER FUNCTION	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
28 Climate Control Unit Rear	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
31 Engine Electronics Conjunct.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
32 Locking Electronisc	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
53 Parking Brake	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
58 Auxiliary Fuel Tank	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
64 Stabilizers	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
1C Vehicle Position Detection	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
2D Voice Amplification	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
3D Special Function	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

6E Roof Display/Control Head	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
7E Ind.Unit in Inst.Panel Ins.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
0D Sliding Door Left	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
7D Auxiliary Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
0F Radio Tuner-Digital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
1F Radio Satellite	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
2F TV TunerDigital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
04 Steering Position	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
74 Vehicle Control System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
3C Lane Departure Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
4C Tyre Pressure Monitor II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
5C Lane Keeping Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
6C Rear Camera	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
5D Opertion	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
6D Electronic Equipment of Trunk Lid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
0B Auxiliary Air Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
5F Information Electronic Equipment 1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
6F Confort Central Control Unit II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
1B Power-Assisted Steering	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
10 Parking Assist System 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
7F Left Slide Door	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
01 Engine electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
11 Engine electronics 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
21 Engine electronics 3	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
02 Transmission Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
03 Brake Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
08 AC/Heating electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
25 Immobilizer	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
47 Soundsystem	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
12 Clutch electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
34 Self leveling suspension	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
15 Airbags	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
16 Steering Wheel Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
44 Steering assistance	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

35 Central Locking	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
14 Wheel damping electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
17 Instrument Cluster	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
18 Aux heating	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
13 Distance control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
19 Gateway data bus	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
26 Electric roof control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
29 Left light control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
39 Right light control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
37 Navigation	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
45 Interior Monitoring	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
46 Central Control Module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
49 Auto. Lighting switch	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
51 Electric drive	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
61 Battery control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
75 Emergency call module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
76 Parking aid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
09 Electronic Ctrl Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
22 4WD Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
24 Drive slip control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
36 Driver`s side seat adj.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
41 Diesel pump electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
55 Headlight range control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
56 Radio	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
65 Type pressure monitoring	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
66 Seat-/mirror adjust.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
71 Battery charger	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
5D Opertion	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
6D Electronic Equipment of Trunk Lid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
0B Auxiliary Air Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
5F Information Electronic Equipment 1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
6F Confort Central Control Unit II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
1B Power-Assisted Steering	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
10 Parking Assist System 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

7F Left Slide Door	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
01 Engine electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
11 Engine electronics 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
44 Steering assistance	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
05 ACCESS & PERMISSI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
21 Engine electronics 3	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
31 Engine Electronics Conjunct.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
61 Battery control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
02 Transmission Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
22 4WD Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
52 PASSE.-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
62 RR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
03 Brake Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
13 Distance control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
53 Parking Brake	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
34 Self leveling suspension	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
15 Airbags	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
25 Immobilizer	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
55 Headlight range control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
65 Tyre pressure monitoring	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
75 Emergency call module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
06 PASSENE. SEAT ADJ.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
16 Steering Wheel Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
26 Electric roof control	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
36 Driver`s side seat adj.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
46 Central Control Module	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
56 Radio	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
66 Seat-/mirror adjust.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
76 Parking aid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
1D Driver identification	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
3D Special Function	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
07 DISPLAY-/CNTL UNIT	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

17 Instrument Cluster	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
37 Navigation	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
47 Soundsystem	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
42 DRIVER-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
52 PASSE.-DOOR ELECT.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
62 LR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
72 RR-DOOR ELECTRONI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
23 BRAKER BOOSTER	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
43 BRAKER BOOST.ASSI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
63 DRVS BOARDING ASS1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
73 DRVS BOARDING ASS2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
54 Rear spoiler	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
05 ACCESS & PERMISSI.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
06 PASSENE. SEAT ADJ.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
07 DISPLAY-/CNTL UNIT	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
27 DIS./CTL UNIT REAR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
57 TV-TUNER	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
67 VOICE CONTROL	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
77 TELEPHONE	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
48 DRVS SEAT ADJ.REAR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
68 WIPER ELECTRONICS	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
78 SLIDING DOOR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
59 TOWING PROTECTION	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
69 TRAILER FUNCTION	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
28 Climate Control Unit Rear	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
31 Engine Electronics Conjunct.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
32 Locking Electronisc	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
53 Parking Brake	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
58 Auxiliary Fuel Tank	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
64 Stabilizers	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
1C Vehicle Position Detection	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
2D Voice Amplification	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
3D Special Function	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

6E Roof Display/Control Head	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
7E Ind.Unit in Inst.Panel Ins.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
0D Sliding Door Left	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
7D Auxiliary Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
0F Radio Tuner-Digital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
1F Radio Satellite	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
2F TV TunerDigital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
04 Steering Position	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
74 Vehicle Control System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
3C Lane Departure Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
4C Tyre Pressure Monitor II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
5C Lane Keeping Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
6C Rear Camera	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
57 TV-TUNER	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
67 VOICE CONTROL	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
77 TELEPHONE	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
0E Media player position 1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
1E Media player position 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
2E Media player position 3	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
3E Media player position 4	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
4E Control head RR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
5E Control head LR	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
7E Ind.Unit in Inst.Panel Ins.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
08 AC/Heating electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
18 Aux heating	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
28 Climate Control Unit Rear	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
38 ROOF ELECTRONICS	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
7D Auxiliary Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
09 Electronic Ctrl Electronics	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
19 Gateway data bus	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
69 TRAILER FUNCTION	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
0F Radio Tuner-Digital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
1F Radio Satellite	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
2F TV TunerDigital	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>

4F Electronic central electric II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
04 Steering Position	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
74 Vehicle Control System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
3C Lane Departure Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
4C Tyre Pressure Monitor II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
5C Lane Keeping Assistance System	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
6C Rear Camera	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
5D Opertion	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
6D Electronic Equipment of Trunk Lid	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
0B Auxiliary Air Heater	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
5F Information Electronic Equipment 1	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
6F Confort Central Control Unit II	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
1B Power-Assisted Steering	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
10 Parking Assist System 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
20 High Beam Assistance Device	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
30 Special Function 2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>
7F Left Slide Door	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>acuat.</i>	<i>spec.</i>